

11. Installation is finished and turn the lamp on.

NOTE:

THIS PRODUCT MUST BE INSTALLED IN ACCORDANCE WITH THE APPLICABLE INSTALLATION CODE BY A PERSON FAMILIAR WITH THE CONSTRUCTION AND OPERATION OF THE PRODUCT AND THE HAZARDS INVOLVED CONSULT A QUALIFIED ELECTRICIAN TO ENSURE CORRECT BRANCH CIRCUIT CONDUCTOR

CE PRODUIT DOIT ÊTRE INSTALLÉ SELON LE CODE D'INSTALLATION PERTINENT, PAR UNE PERSONNE QUI CONNAÎT BIEN LE PRODUIT ET SON FONCTIONNEMENT AINSI QUE LES RISQUES INHÉRENTS. CONSULTER UN ÉLECTRICIEN QUALIFIÉ POUR VOUS ASSURER QUE LES CONDUCTEURS DE LA DÉRIVATION SONT ADÉQUATS

LE PRO LED Semi-Cutoff Wall Pack Light Instruction

Application:

Available in industrial lighting, landscape lighting, courtyard, building, hotel, building exterior, etc.


Caution:

1. Please don't use the electric generator to test the LED lamp.
2. Please abide by related country, regional and local law and regulations when install this fixture.
3. Please don't install the fixture when it's raining to lower the risk of electric shock and avoid failure.


Note:

1. To avoid possibility of electrical shock or fire, the installation personnel must have professional electric knowledge.
2. Please wear gloves to avoid injury before installation.
3. If any smoke or spark happened, please turn off the power immediately and notify relevant personnel.


Installation I:




1. Turn off the power.




2. Unscrew the 4 screws of the lamp cover and the rubber sleeve on the screw must not be discarded.




3. Remove the lamp cover, take care not to damage the lamp cover.




4. Make mounting holes on the wall according to the size shown in the picture. Use an electric drill to drill through the mounting holes on the lamp.




5. Remove the 1/2 plug with a screwdriver.




6. Attach the EVA pad to the relevant position on the back of the lamp.




7. Run the power line through the hole.




8. Screw the lamp onto the mounting holes.




3. Remove the lamp cover, take care not to damage the lamp cover.




4. Remove the 1/2 plug with a screwdriver.




9. Connect the wires correctly and make good protection. Pull out the wire connected to photocell if photocell function is not demanded.




10. Assemble the lamp cover back to the lamp.




5. Attach the EVA pad to the relevant position on the back of the lamp.




6. Run the power line through the hole.




11. Fasten the lamp cover to the lamp body with kit rubber ring.



12. Installation is finished and turn the lamp on.




7. Drill through the mounting holes of the mounting plate with an electric drill and screw the lamp onto the mounting plate.




8. Connect the wires correctly and make good protection. Pull out the wire connected to photocell if photocell function is not demanded.


Installation II:




1. Turn off the power.



2. Unscrew the 4 screws of the lamp cover and the rubber sleeve on the screw must not be discarded.



9. Assemble the lamp cover back to the lamp.



10. Fasten the lamp cover to the lamp body with kit rubber ring.